

Patches Using Instruction

Way 1:

Sew the edges of patch with similar colour thread to the surface of your cloth or fabric directly.

Way 2:

Put the patch to your clean, dry, room temperature surface and, gently cover patch with paper towel and apply with a low temperature (around 120-150°) iron (no steam) for 1 minute. Remove iron and press firmly with your fingers over the entire surface of patch with extra focus on the edges for 1 minute. Then repeat until satisfied with application.

